

Product/Maintenance information no. 2017-2

Date: 2017-11-27

Created / Approved by: Martin Johansson

Announcement concerning Check valve No 39309.

Background and Measures

Since January 2016, Check valve 39309 (see Pic 1) has been delivered on the VCC II units and as spare part for the pressure side of the dosing pump on the VCC II.

We have now experienced a couple of failures because of the Glas ball 36574 (see Pic 2), falling down into the dosing pump, after (for a long time) being "eaten" to smaller size by the chemical concentrate.

We therefor recommend that Glas ball 36574, is changed to SS ball 36575 (see Pic 3) as soon as possible or during next maintenance visit to customer.

We also ask you to look on your stock and see if you have any 39309, and if so, please change to SS ball 36575.

Please, also be informed that we from now on, move over to SS ball 36575 in all Check valves 39309, both on VCC II units and as spare part.

We are sorry for this inconvenience, but we are doing what we can to minimize the damage.

If you have any questions, please contact us.

Lagafors Fabriks AB



Pic 1



Pic 2



Pic 3



